




How to remove and clean iRobot Roomba 655 Pet Series brushes

How to remove and clean all the brushes on your Roomba.



Written By: Matt Davis



INTRODUCTION



It is recommended to clean your Roomba every week (depending on how often you use it).

Step 1 — How to remove and clean iRobot Roomba 655 Pet Series brushes



- Push down on the two yellow tabs, and pull open the brush gate gently

Step 2 — Removing The Brushes



- Grab and pull up on the brushes to remove them
- Use a damp microfiber or terry cloth to clean the rubber brush

Step 3 — Cleaning the Bristle Brush



- Use the included hair cutter to cut through hair that has gotten caught in the brush
- Slide the brush cleaner down and back up until your brush is clean

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 03:01:33 AM.